

**SUNSHADE INSTALLATION
INSTRUCTION
HON-CRV-5-X**



X2

X2

X1

X1



X6

X4

X2

X1

PRE-INSTALLATION WARNING.

THE ADHESION PROMOTER SUPPLIED IS TO BE USED ON ALL AREAS WHERE AN ADHESIVE BACKED CLIP IS REQUIRED. WIPE THE AREA WHERE THE CLIP IS POSITIONED BEFORE PRESSING AND HOLDING THE CLIP IN PLACE.



HON-CRV-5-X





HON-CRV-5-X

