

Installation Manual

INFINITI Q30 5DR
INF-Q30-5-A-18



Shades



1+8

Side Shades

Fixing Clips



CL-M11 x 6



CL-T01 x 1



Installation

INFINITI Q30 5DR
INF-Q30-5-A-18

Components Needed



Side Shades



CL-M11 x 6



CL-T01 x 1

Side Shade Installation

STEP #1

INSERT CLIPS INSIDE WEATHERSTRIP



STEP #2

POSITION THE SIDE SHADE



STEP #3

ATTACH SIDE SHADE BEHIND CLIPS



STEP #4

ENSURE SECURELY FITTED IN PLACE

