

# Installation Manual

SKODA SUPERB 5DR  
SKO-SUPE-5-C-18



## COMPONENTS INCLUDED



## FIXING CLIPS



CL-M11 x 6



CL-M03 x 2



CL-T01 x 1



# Side Shade Installation

SKODA SUPERB 5DR  
SKO-SUPE-5-C-18

COMPONENTS NEEDED:



-  CL-M11 x 6
-  CL-M03 x 2
-  CL-T01 x 1

## STEP #1

INSERT CLIPS INSIDE WEATHERSTRIP



## STEP #2

ATTACH CLIPS ON SHADE EDGE



## STEP #3

POSITION THE SIDE SHADE



## STEP #4

ATTACH SIDE SHADE BEHIND CLIPS



## STEP #5

ENSURE SECURELY FITTED IN PLACE



**CAR**  
SHADES