

# Installation Manual

VW T-ROC 5DR  
VW-TROC-5-A-18



## Shades

## Fixing Clips



Side Shades



CL-M05 x 4



CL-T01 x 1



# Installation

VW T-ROC 5DR  
VW-TROC-5-A-18

## Components Needed



Side Shades



CL-M05 x 4



CL-T01 x 1

## Side Shade Installation

### STEP 1



### STEP 2



### STEP 3



Peel back the rubber trim using the CL-T01 tool

### STEP 4



### STEP 5



### STEP 6



Peel back the rubber trim using the CL-T01 tool

# Installation

VW T-ROC 5DR  
VW-TROC-5-A-18



## Side Shade Installation

### STEP 7



### STEP 8



### STEP 9



### STEP 10



### STEP 11



### STEP 12



**Repeat this whole process for the other side.**