




JIMNY - SUN BLIND INSTALLATION INSTRUCTIONS

PART NUMBER SIE: 990E0-81A00-000


GB: 9904A-00013

VEHICLE DESCRIPTION:


JIMNY SUNBLINDS



HARDWARE KIT



x2




x2




x1



x1



x4









x4

Warning

Read these fitting instructions carefully before you start the installation. Rear passenger windows must not be lowered more than 1/3 whilst the blinds are fitted and the vehicle is in motion. Blinds must not be used during the hours of darkness. On installation care must be taken not to scratch any paintwork with clips.

JIMNY - SUN BLIND INSTALLATION INSTRUCTIONS



WARNING:

Read these fitting instructions carefully before you start the installation. Rear passenger windows must not be lowered more than 1/3 whilst the blinds are fitted and the vehicle is in motion. On installation care must be taken not to scratch any paintwork with clips.